Toshiba personal computers are sold all around the world. To accomodate this, the computers are customized for the local markets.

Models may have different keyboards, power adapters, power cords, et cetera, depending on their intended market.

The country configuration of the computer may be determined from the $% \left(1\right) =\left(1\right) +\left(1\right$

 $\mbox{'PA'}$ number on the Serial Number sticker on the machine. For example,

the 'PA' number of a Tecra 700CT/1.2 is PA1214**XT, where the '**' is

one of the following:

E = Europe
EA = Australia

EY = Europe (specifically Northern/Scandinavian)

U = USA UC = Canada

UK = Europe (specifically United Kingdom of Great

Britain)

A Canadian machine would be: PA1214UCXT

(On the serial number sticker, a space may appear after, or between the $\ensuremath{\mathsf{I}}$

two characters of the coutry code; PA1214U CXT)

In the Toshfax Service Parts Lists ('Remarks' column) and on Toshiba's

Service CD-ROM (ATLAS-i) Parts Catalogs ('Comments' column), an abbreviation is used to differentiate the country-specific parts:

TAIS = USA

TAP = Australia

TCL = Canada TEG = Europe

in the Parts Catalogs. Please take care when ordering replacement parts, to ensure that you order the correct country specific part.